

BRUKSANVISNING FÖR LED ARMATUR

Modell: 72W 36x2W UV

IP20 klass, enbart för inomhusbruk (utomhus under varma förhållanden utan regn).

Strömförsörjning: Nätdrift

Fjärrkontroll

Läs användarmanualen innan du börjar använda enheten.

1. Knappfunktion

Enheten har en digital display som visar numeriska värden (t.ex. 20, 40, 60) och fyra kontrollknappar: MENY, UPP, NER och ENTER. Dessa knappar används för att navigera i menyer, justera inställningar och bekräfta val. Displayen visar även inställningar för trådlös DMX-kod.

2. Menystyrning

| Meny | Function Description |
|-----------|---|
| D001-D512 | DMX mode |
| CC01-CC64 | Color selection (up/down) |
| RB01-RB16 | Color shades (up/down) |
| PK01-PL16 | Color pulse (up/down) |
| SD01-SD16 | Color transition (up/down) |
| FL01-FL16 | Color strobe (up/down) |
| Sound | Sound control mode |
| R000-R255 | Manual set, purple color brightness (up/down) |
| G000-G255 | Manual set, purple color brightness (up/down) |
| B000-B255 | Manual set, purple color brightness (up/down) |

3. DMX-kanalfunktion

| Kanal | Display | Function Description |
|-------|--|---|
| CH1 | 0-255 | Color brightness control (this change should be used together with CH2, CH3 or CH4) |
| CH2 | 0, 1-255 | Purple light off, Purple brightness (from dark to light) |
| CH3 | 0, 1-255 | Purple light off, Purple brightness (from dark to light) |
| CH4 | 0, 1-255 | Purple light off, Purple brightness (from dark to light) |
| CH5 | 0-7, 8-255 | No strobe flash, Strobe flash (from slow to fast) |
| CH6 | 0-10 11-60 61-110 111-160 161-210 211-255 | Manual control (CH1-CH5) Color selection (color controlled by CH7) Color chading (color controlled by CH7) Color puls transform (speed controlled by CH7) Color transition (speed controlled by CH7) Sound control |
| CH7 | 0-255 | Color selection/colors shade (from slow to fast) |



