

BRUKSANVISNING FÖR LED ARMATUR

Modell: 4-i-1 RGBW

IP20 klass, enbart för inomhusbruk (utomhus under varma förhållanden utan regn).

Strömförsörjning: Nätdrift

Läs användarmanualen innan du börjar använda enheten.

1. Knappfunktion

Enheten har en digital display som visar numeriska värden (t.ex. 20, 40, 60) och fyra kontrollknappar: MENY, UPP, NER och ENTER. Dessa knappar används för att navigera i menyer, justera inställningar och bekräfta val. Displayen visar även inställningar för trådlös DMX-kod.

2. Menystyrning / DMX-kanalfunktion

Kanal	Display	Function Description
CH1	d001	Address code (001-512)
CH2	8Ch/4Ch	8-4 channel selection
CH3	Au01 - Au08 Au09 Au10 So01 So02	Au01- Au08 Fixed color selection Au09 Jump Au10 Gradient So01 Sound 1 So02 Sound 2
CH4	St00 St01 - St16	St00 No strobe St01-St16 Strobe from slow to fast
CH5	SP00 SP01 - SP16	SP00 SP01-SP16 Auto speed from slow to fast
CH6	r255	Red color selection (000-255)
CH7	g255	Green color selection (000-255)
CH8	b255	Blue color selection (000-255)
CH9	u255	White color selection (000-255)

8CH:

No.	Function	Description
1CH	Total dimming	R;G;B;W total dimming, linear dimming, from dark to bright
2CH	R dimming	R dimming, linear dimming, from dark to bright
3CH	G dimming	G dimming, linear dimming, from dark to bright
4CH	B dimming	B dimming, linear dimming, from dark to bright
5CH	W dimming	W dimming, linear dimming, from dark to bright
6CH	Total strobe	R;G;B;W total strobe, from slow to fast
7CH	Function selection	0-3-DMX channel control: 4-127-8: fixed color 128-169: jump 170-210: gradient 211-229: sound 1 230-255: sound 2
8CH	Function speed	Function speed, from slow to fast

4CH:

No.	Function	Description
1CH	R dimming	R dimming, linear dimming, from dark to bright
2CH	G dimming	G dimming, linear dimming, from dark to bright
3CH	B dimming	B dimming, linear dimming, from dark to bright
4CH	W dimming	W dimming, linear dimming, from dark to bright



