

# BRUKSANVISNING FÖR LED ARMATUR

Modell: Modern PAR armatur 9pcs RGBW

IP20 klass, enbart för inomhusbruk (utomhus under varma förhållanden utan regn).

Strömförsörjning: Nätdrift

Fjärrkontroll

Läs användarmanualen innan du börjar använda enheten.

## 1. Knappfunktion

Enheten har en digital display som visar numeriska värden (t.ex. 20, 40, 60) och fyra kontrollknappar: MENY, UPP, NER och ENTER. Dessa knappar används för att navigera i menyer, justera inställningar och bekräfta val. Displayen visar även inställningar för trådlös DMX-kod.

## 2. Menystyrning / DMX-kanalfunktion

No	Show	Value	Function and description
1	A001	A512	512 8CH mode
2	AdyE	Adno	512 priority
3	AU01	AU08	Chose color
4	FF00	FF99	Self walking, changing color, speed
5	EE00	EE99	Color gradient, from slow to fast
6	CC00	CC99	Color pulse change, from slow to fast
7	F000	F255	Stroboscope, from slow to fast
8	Sound	Sound	Sound controlled stroboscope
9	Sund	Sund	Voice controled change
10	r000	r255	Red maximin brightness setting
11	g000	g255	Green maximin brightness setting
12	b000	b255	Blue maximin brightness setting
13	u000	u255	White maximin brightness setting
14	rEyE	rEno	Remote control on and off

### 8CH:

No.	Function	Description
1CH	Total dimming	R;G;B;W total dimming, linear dimming, from dark to bright
2CH	R dimming	R dimming, linear dimming, from dark to bright
3CH	G dimming	G dimming, linear dimming, from dark to bright
4CH	B dimming	B dimming, linear dimming, from dark to bright
5CH	W dimming	W dimming, linear dimming, from dark to bright
6CH	Total strobe	R;G;B;W total strobe, from slow to fast
7CH	Function selection	Color selection, Gradual change, Pulse change, Voice control
8CH	Function speed	Function speed, from slow to fast



